



# Gun Cleaner Equipment Maintenance Guidelines

Guidelines for regular maintenance or a quick system cleaning

---

1. Turn off the power to your machine
2. Remove the transfer pump from the material drum and thoroughly clean any ISO (A) or Resin (B)
3. Place the transfer pump in a 5 Gallon bucket and pour in 4 Gallons of PURclean Gun Cleaner.
4. Attach an air line with 100 PSI to the pump, then remove your Spray Gun from the end of the hose.
5. Open the manual valve on the manifold over a waste bucket and pump between 3 and 4 gallons through the pump and hose until Gun Cleaner starts coming out of the manifold. Close the valve.
6. Add an additional 3 gallons of Gun Cleaner into the bucket with the transfer pump.
7. Next, add a mesh filter to the bucket and hold the spray hose over the Gun Cleaner bucket and open the manual valve. Allow to circulate for 15-30 minutes without heat, until no signs of crystallized ISO or debris are visible in the mesh filter. Add 30 more minutes if necessary.
8. After circulation is done, close the manual valve.
9. Put the drum pumps back into their respective drums and flush out the Gun Cleaner with fresh material.
10. For rigs with recirculation lines, proceed with flushing those lines with Gun Cleaner until clean and flush with fresh material.

PURclean Solutions Operation/Procedure Manual - 2026

\*This product is for use only with spray foam equipment. Use outside of specific equipment is not recommend and PURclean assumes no liability for misuse

\*Be sure to use proper Personal Protection Equipment (PPE) for eye protection, hand protection, and respiratory protection when using the product

\*Always follow the equipment manufacturer's guidelines when using our products.